

## **How do I turn the BGM (background music) on/off?**

If you do not have Music On Hold device connected to your telephone system and you inadvertently turn BGM on, you may hear a white noise or hiss through your speaker during quiet times. Simply turn off the BGM as indicated.

### **KX-TDA50, KX-TDA100 and KX-TDA200 telephone systems**

On: INTERCOM, STAR, 7511

Off: INTERCOM, STAR, 7510

### **KX-TD308, KX-TD816, KX-TD1232, KX-TD500, KX-TD1232-11, KX-T308 and KX-T616 telephone systems**

On: PRESS 1 (with handset down and the speakerphone off)

Off: PRESS 1 (with handset down and the speakerphone off)