

## Time Set KX-TDA 50/100/200

*The KX-TDA system automatically adjusts for Daylight Savings Time*

### **KEYSTROKES**

*(Press these keys)*

Press **PROGRAM, STAR, STAR, 1234 (or your password)**

*(Default password is 1234. yours may have been changed)*

Press SP-PHONE

Press the button below ENTER on the display or the ENTER in the middle of the Navigator Wheel      Display will show year, month and date

Press the button below NEXT on the display      Display will show flashing hour.

Enter the 2-digit hour      Such as 03 or 11

Enter the 2-digit minute      Such as 06 or 44

If needed, set AM or PM      Not necessary if correct

Press ENTER on the Navigator Wheel or the button labeled Auto Dial/Store.      New time is now stored.

Lift handset and hang up to leave programming mode or press exit